

## Cyclone Timing Module Express8 Installation Notes

### WARNING

**DO NOT PLUG THE POWER SUPPLY INTO ITS POWER SOURCE PRIOR TO CONNECTING THE POWER CORD TO THE CTM EXPRESS8. DOING SO MAY CAUSE IREPERABLE DAMAGE TO YOUR TIMING MODULE.**

It is recommended that you limit your Timing cable lengths to 50 ft. or less and your POE Cat5 to no more than 328 ft.

### RJ-12 Straight-thru GPS Sync Cable Wiring Diagram

Pin 1 → white / orange ← Pin 1  
Pin 2 → white / green ← Pin 2  
Pin 3 → white / blue ← Pin 3  
Pin 4 → green ← Pin 4  
Pin 5 → blue ← Pin 5  
Pin 6 → orange ← Pin 6

**NOTE:** The fourth pair is not used.

